



FITTING INSTRUCTIONS

- 1- Cut the Lean-to Flashing Trim to the overall width of the roof glazing including both end rafters.
- 2- Fit gasket into groove which suits the roof pitch (angle).
- 3- Drill 4mm holes in one of the 'V' lines to suit fixings to the wall and counter sink to 7mm. (Recommended centres of 600mm max)
- 4- Hold the Lean-to Flashing Trim in place whilst pressing down onto the glazing to compress to gasket, mark the wall for the fixing screws, drill and plug wall.

